



Care & installation guide for your Digitally printed banners

Installation guide

When hanging your banner, use as many of the grommets that you can. Your banner will last longer and look better if you don't let it droop in the middle. On the other hand, it can not withstand being pulled excessively tight. During severe weather, take down your banner. Most banners are not made to withstand high winds.

Care and maintenance guide

Storing your banner properly will extend its life. Don't fold your banner. Roll it with the letters facing in. Store it standing on end. An occasional wash with a mild detergent and water with a soft sponge will do wonders to extend their life but make sure it is completely dry before rolling and storing.

After cleaning your banner roll the banner onto a cardboard tube lettering side in. Do not store in extremely warm places. For best results store banners in a closet or storeroom at temperatures ranging from 10 C to 30 C. Never fold your banner, or roll it without a tube, this can cause permanent creases.

If you use your banner in a hot environment, the banner may be warm or even hot to touch when you take it down. this is the time when your banner is the most fragile. Handle it gently, and try not to get creases in it. If at all possible lay your banner in the shade for 15-30 minutes before rolling it onto the cardboard tube. Remember to protect the printing on a printed banner always roll it printed side in.

NEVER fold - ALWAYS roll

NEVER lay banner face to face

NEVER use abrasives to clean the surface

NEVER store when wet or hot

This information is to be used as a guide only and does not constitute a warranty.